



RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	3359	Line Roller Washer	5690	Anti-Reverse Lever Screw
0071	Rotor Nut	3402	Cover Screw	5996	Locking Spring
0452	Drag Spring Washer	3681	Bail Spring Guide (A)	6797	Bail Spring Cover
0540	Multi-Purpose Screw	3682	Bail Spring	7290	Push Button
0579	Eared Washer "B"	3683	Bail Spring Guide (B)	7295	Ball Bearing
0584	Hold Click Spring	3747	Slider Retainer Screw	7298	Anti-Reverse Lever
0779	Multi-Purpose Screw	3765	Drag Click	7305	Drag Spring
0787	Nut Lock Screw	3794	Drag Knob Screw	7314	Push Button Collar
0792	Bearing Retainer Screw	3866	Bail Trip Lever	7315	Spool Assembly
0826	Key Washer "A"	3869	Anti-Reverse Lock Out Spring	7316	Main Shaft
0848	Small Hole Washer	3873	Anti-Reverse Pawl Spring	7317	Bail Assembly
1008	Handle Lock Washer	4049	Large Hole Washer	7318	Rotor
1511	Lever Spring	4274	Drag Shaft	7319	Counterbalance Cover
1520	Anti-Reverse Cam Spring	4306	Lock Out Spring Holder	7320	Pinion Gear
1596	Bushing Washer	4307	Anti-Reverse Lock Out	7321	Anti-Reverse Cam
2016	Drag Washer "H" (cloth)	4308	Anti-Reverse Pawl	7322	Drive Gear
2257	Drag Washer "H" (blue)	4362	Side Cover Screw	7323	Oscillating Slider Retainer
2293	Drive Gear Bushing	4367	Line Roller Screw	7324	Oscillating Slider Inner
2346	Drag Washer "C" (cloth)	4572	Bail Arm	7325	Oscillating Slider
2419	Handle Screw Cap	5625	Line Roller Spacer	7326	Oscillating Gear
2433	Pressure Screw	5628	Line Roller Collar	7327	Drag Knob
2541	Anti-Reverse Pawl Screw	5629	Line Roller Bushing	7328	Handle Assembly
2852	Handle Screw Lock	5630	Line Roller	7329	Body Set