


# Alivio



RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0521	Rotor Nut	3994	Bail Trip Lever	5642	Line Roller
0690	Drive Gear Washer	3996	Anti-Reverse Lock Out	5690	Anti-Reverse Lever Screw
0779	Bail Hold Support Screw	3997	Anti-Reverse Lock Out Spring	6817	Bail Spring Cover
0787	Nut Lock Screw	3998	Lock Out Spring Holder	6818	Counterbalance Cover
1008	Handle Lock Washer	3999	Bearing Retainer Screw	7638	Drag Knob Assembly
1511	Lever Spring	4000	Anti-Reverse Pawl	7639	Spool Assembly
1520	Anti-Reverse Cam Spring	4001	Anti-Reverse Pawl Spring	7640	Main Shaft
2532	Bail Spring Guide (A)	4004	Drive Gear Bushing	7642	Anti-Reverse Cam
2533	Bail Spring	4005	Drive Gear	7643	Anti-Reverse Lever
2534	Bail Spring Guide (B)	4006	Oscillating Gear Bushing	7644	Handle Screw Cap
2541	Anti-Reverse Pawl Screw	4019	Counterbalance Cover Screw	7645	Oscillating Slider
3182	Spool Support	4367	Line Roller Screw	7646	Oscillating Gear
3191	Bail Spring Cover Screw	4581	Bail Arm	7661	Rotor
3195	Bushing	4624	Bail Arm Screw	7662	Bail Assembly
3359	Line Roller Washer	4627	Side Cover Screw (large)	7663	Handle Assembly
3387	Handle Screw Lock	4628	Side Cover Screw (small)	7664	Body Assembly
3665	Slider Retainer Screw	5625	Line Roller Spacer	7965	Oscillating Slider Inner
3949	Pinion Gear	5628	Line Roller Collar	8372	Ball Bearing
3990	Spool Washer	5629	Line Roller Bushing	8374	Ball Bearing