



AX6000FA 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0244	Ball Bearing	2722	Counterbalance Cover Screw	4006	Oscillating Gear Bushing
0345	Anti-Reverse Lever Screw	3182	Spool Support	4007	Oscillating Gear
0521	Rotor Nut	3195	Bushing	4008	Oscillating Slider
0690	Drive Gear Washer	3202	Anti-Reverse Lever	4581	Bail Arm
0787	Nut Lock Screw	3359	Line Roller Washer	4582	Side Cover Flange
0940	Bail Hold Support Screw	3387	Handle Screw Lock	4627	Side Cover Screw (large-silver)
1008	Handle Lock Washer	3949	Pinion Gear	5625	Line Roller Spacer
1109	Slider Retainer Screw	3987	Drag Knob	5628	Line Roller Collar
1310	Line Roller Screw	3989	Main Shaft	5629	Line Roller Bushing
1511	Lever Spring	3990	Spool Washer	5642	Line Roller
1520	Anti-Reverse Cam Spring	3994	Bail Trip Lever	6815	Bail Assembly
1863	Handle Screw Cap	3996	Anti-Reverse Lock Out	6816	Rotor
2342	Side Cover Screw (large-black)	3997	Anti-Reverse Lock Out Spring	6817	Bail Spring Cover
2530	Bail Spring Cover Screw	3998	Lock Out Spring Holder	6818	Counterbalance Cover
2532	Bail Spring Guide (A)	3999	Bearing Retainer Screw	6819	Handle Assembly
2533	Bail Spring	4000	Anti-Reverse Pawl	7269	Spool Assembly
2534	Bail Spring Guide (B)	4001	Anti-Reverse Pawl Spring	7270	Side Cover
2541	Anti-Reverse Pawl Screw	4002	Anti-Reverse Cam	7271	Body
2548	Side Cover Screw (small)	4004	Drive Gear Bushing		
2571	Bail Arm Screw	4005	Drive Gear		