


BAITRUNNER AERO



GTE6000 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	4403	Line Roller Screw	7189	Clutch Pawl
0041	Drive Gear Washer	4480	Rotor Protector Screw (small)	7190	Clutch Plate Assembly
0050	Anti-Reverse Cam Plate Screw	4649	Spacer	7191	BaitRunner Click Spring
0071	Rotor Nut	4656	Trip Lever Spacer	7192	Side Cover Flange
0153	Drag Coil Spring	4714	Roller Clutch Assembly	7194	Side Cover Screw (medium)
0345	Anti-Reverse Lever Screw	5311	Anti-Reverse Lever	7195	BaitRunner Lever Arm (L)
0611	Hold Click Spring	5625	Line Roller Spacer	7196	BaitRunner Lever Bridge
0642	Clutch Plate Screw	5823	Lever Spring Guide (A)	7197	Clutch Shaft Spring
0930	Ball Bearing	5825	Lever Spring Guide (B)	7198	Dial Click Spring
0959	Bail Hold Support Screw	5859	BaitRunner Lever Spacer	7199	Dial Click Shoe
1008	Handle Lock Washer	5909	Line Roller Bushing	7200	Drag Washer "C"
1506	Clutch Cover Screw	5910	Line Roller	7201	Click Gear
2109	Eared Washer "B"	5941	Side Cover Screw (short)	7202	Eared Washer "Brs"
2309	Slider Retainer Screw	5954	BaitRunner Lever Screw	7203	Double Paddle Handle Assembly
2548	Side Cover Screw (long)	6289	Nut Retainer Screw	7204	Lock Washer (A)
2549	Oscillating Slider Retainer	6380	Bail Spring Guide (A)	7205	BaitRunner Lever Arm (R)
2551	Oscillating Slider Bushing	6383	Bail Spring Guide (B)	7207	Dial Spacer
2553	Oscillating Slider	6623	Bearing Spacer	7208	Spacer
2569	Drag Knob Screw	6679	Nut Retainer	7209	Drag Washer "H" (black)
2570	BaitRunner Clutch Screw	6686	Click Spring	7210	Pressure Screw
2605	Clutch Pawl Spring	6687	Bail Arm Click	7211	Dial Washer
2610	Clutch Spring	6711	Rotor Support Bushing	7212	BaitRunner Tension Dial
2611	BaitRunner Lever Shaft	6719	Friction Ring	7213	Dial Retainer Ring
2613	Lock Washer (B)	6742	Handle Screw Cap	7214	Drag Knob
2614	BaitRunner Lever Screw (B)	6759	Bail Arm Screw	7215	Spool Assembly
2620	Clutch Screw Collar	6760	Bail Spring Guide (A) Collar	7216	Main Shaft
2621	BaitRunner Clutch	6762	Bail Arm	7217	Bail Spring
2622	Clutch Shaft	6763	Rotor Protector Screw (large)	7218	Bail Spring Cover
2624	Drag Washer "C" (blue)	6764	Spacer	7219	Bail Spring Cover Guard
2630	Free Spool Tension Shaft	6765	Bail Hold Support Spacer	7220	Bail Trip Lever
2631	Drag Washer "D"	6768	Spacer	7221	Bail Assembly
2632	Drag Shaft	7139	Bail Hold Support Shaft	7222	Rotor
2633	Drag Washer "H" (cloth)	7176	Line Roller Washer	7223	Lever Spring
2635	Key Washer "A"	7180	Friction Ring Screw	7224	Guard Ring
2852	Handle Screw Lock	7181	Worm Bushing	7225	Pinion Gear
3282	Roller Clutch Screw	7182	Idle Gear	7226	Worm Shaft
3306	Line Roller Bearing	7185	Anti-Reverse Cam Plate	7227	Side Cover
3655	Guard Ring Screw	7186	Anti-Reverse Cam Spring	7228	Body
3962	Spacer	7187	Anti-Reverse Cam		
4325	Oscillating Pawl	7188	Drive Gear		