


BIOMASTER III



3000 97

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	2852	Handle Screw Lock	3867	Counterbalance Cover
0041	Drive Gear Washer	2934	Flange Screw	3868	Lock Out Spring Holder
0071	Rotor Nut	3359	Line Roller Washer	3869	Anti-Reverse Lock Out Spring
0345	Anti-Reverse Lever Screw	3503	Spool Washer	3870	Anti-Reverse Lock Out
0543	Side Cover Screw (small)	3655	Cover Screw	3871	Bushing Washer
0787	Nut Lock Screw	3665	Slider Retainer Screw	3872	Anti-Reverse Pawl
0792	Bearing Retainer Screw	3676	Drag Knob	3873	Anti-Reverse Pawl Spring
0930	Ball Bearing	3677	Main Shaft	3874	Anti-Reverse Cam
0940	Multi-Purpose Screw	3681	Bail Spring Guide (A)	4163	Line Roller Bushing
1008	Handle Lock Washer	3682	Bail Spring	4351	Anti-Reverse Lever
1310	Line Roller Screw	3683	Bail Spring Guide (B)	4360	Side Cover Flange
1442	Handle Screw Cap	3690	Pinion Gear	4395	Handle Assembly
1506	Multi-Purpose Screw	3694	Drive Gear	4553	Line Roller
1511	Lever Spring	3695	Oscillating Gear	4571	Bail Assembly
1520	Anti-Reverse Cam Spring	3696	Oscillating Slider	4572	Bail Arm
1676	Side Cover Screw (large)	3863	Rotor	5109	Spool Assembly
2516	Spool Support	3865	Bail Spring Cover	5110	Side Cover
2541	Anti-Reverse Pawl Screw	3866	Bail Trip Lever	5111	Body