


CALCUTTA TE



200 01

BNT No.	PARTS NAMES	BNT No.	PARTS NAMES	BNT No.	PARTS NAMES
0001	Handle Nut Plate Screw	2228	Damper Guide Screw	2444	Pinion Gear
0011	Drive Shaft Retainer Screw	2396	Roller Clutch Bearing	2445	Yoke Spring
0015	Drag Spring Washer	2404	Anti-Reverse Pawl	2446	Yoke
0032	Bearing Retainer	2417	Handle Nut	2447	Clutch Cam
0060	Spacer (optional)	2419	Star Drag	2448	Clutch Plate
0133	Worm Shaft Retainer	2420	Star Drag Bearing	2449	Clutch Pawl
0194	Ball Bearing	2421	Roller Clutch Inner Tube	2450	Clutch Pawl Spring
0586	Bolt Retainer	2422	Right Side Plate Screw (short)	2451	Set Pin
0664	Spacer (B)	2424	Right Side Plate Screw (long)	2452	Clutch Bar Guide (A)
0686	"E" Lock	2425	Side Plate Open Nut	2453	Clutch Bar Support
0687	Spacer	2426	Open Nut Washer	2454	Clutch Bar Guide (B)
0799	Friction Washer	2427	"O" Ring	2455	Quick-Fire II Clutch Bar
1218	Idle Gear (A) Spacer	2428	Cast Control Cap	2456	Line Guide
1237	Shield Screw	2429	"O" Ring	2457	Pawl Cap
1636	Clutch Cam Screw	2430	Key Washer	2458	Anti-Reverse Pawl Pin
1671	Worm Shaft Washer (B)	2431	Drag Washer (C)	2460	Worm Bushing (B)
1672	"E" Lock	2432	Drive Gear	2461	Damper (A)
1696	Cast Control Spacer (B)	2433	Drag Washer (A)	2462	Damper Guide
1713	Brake Collar (green)	2434	Anti-Reverse Ratchet	2464	Brake Case
1727	Handle Nut Plate	2435	Drive Shaft	2465	Left Side Plate
2127	Star Drag Spacer	2436	Idle Gear (A)	2466	Handle Assembly
2128	Bearing Washer	2437	Drive Shaft Retainer	2467	Right Side Plate
2143	Ball Bearing	2438	Frame Shield	2468	One-Piece Frame
2150	Line Guide Pawl	2439	Level Wind Guide	2469	Spool Assembly
2165	Clutch Cam Retainer	2440	Idle Gear (C)		
2170	Ball Bearing	2441	Worm Bushing (A)		
2177	Left Side Plate Spring	2442	Worm Shaft		
2224	Spool Tension Spacer (A)	2443	Level Wind Guard	1715	Brake Collar (red)

(121023)