



CA-200 ⁹⁵

BNT No.	PARTS NAMES	BNT No.	PARTS NAMES	BNT No.	PARTS NAMES
0015	Drag Spring Washer	1325	Drive Gear	1498	Worm Shaft Assembly
0031	Ball Bearing	1356	Brake Case Retainer Screw	1499	Clutch Plate Screw
0032	Bearing Retainer	1357	Brake Case	1500	Clutch Plate
0042	Line Guide Pawl	1362	Turnkey Pawl	1501	Yoke
0194	Ball Bearing	1365	Star Drag Nut	1503	Clutch Pawl
0425	"E" Lock	1462	Clutch Cam Retainer	1507	Spool Assembly
0664	Spacer (B)	1465	Clutch Pawl Spring	1510	Turnkey Dial
0817	Multi Purpose Screw	1467	Level Wind Guard	1585	Handle Assembly
0830	Spacer (optional)	1475	Disengage Clutch	1586	Right Side Plate
0987	Clutch Cam Screw	1486	Star Drag	1587	Pinion Gear
1092	Pawl Cap	1487	Cast Control Cap Assembly	1588	Clutch Cam
1106	Star Drag Spring	1489	Side Plate Screws	1589	Clutch Plate (B)
1133	Yoke / Turnkey Pawl Spring	1490	Anti-Reverse Ratchet	1590	Thumb Rest
1206	Roller Clutch Inner Tube	1491	Drive Shaft	1591	Line Guide
1207	Roller Clutch Bearing	1492	Idle Gear	1592	Engage Clutch
1211	Key Washer	1493	Drive Gear Washer	1593	Thumb Rest Support
1212	Drag Washer (C)	1494	Drive Shaft Washer (B)	1594	One-Piece Frame
1214	Drag Washer (A)	1495	Drive Shaft Washer (A)	1595	Left Side Plate
1289	Star Drag Spacer	1496	Drive Shaft Cover	1596	Retractor Spring
1317	Brake Collars (red-6 pieces)	1497	Drive Shaft Cover Screw	1597	Retractor Spring Pin