



RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	3402	Cover Screw	5996	Locking Spring
0071	Rotor Nut	3681	Bail Spring Guide (A)	6797	Bail Spring Cover
0452	Drag Spring Washer	3682	Bail Spring	7290	Push Button
0540	Multi-Purpose Screw	3683	Bail Spring Guide (B)	7295	Ball Bearing
0579	Eared Washer "B"	3747	Slider Retainer Screw	7298	Anti-Reverse Lever
0584	Hold Click Spring	3765	Drag Click	7305	Drag Spring
0779	Multi-Purpose Screw	3794	Drag Knob Screw	7314	Push Button Collar
0787	Nut Lock Screw	3866	Bail Trip Lever	7315	Spool Assembly
0792	Bearing Retainer Screw	3869	Anti-Reverse Lock Out Spring	7316	Main Shaft
0826	Key Washer "A"	3873	Anti-Reverse Pawl Spring	7317	Bail Assembly
0848	Small Hole Washer	4049	Large Hole Washer	7319	Counterbalance Cover
1008	Handle Lock Washer	4274	Drag Shaft	7321	Anti-Reverse Cam
1511	Lever Spring	4306	Lock Out Spring Holder	7323	Oscillating Slider Retainer
1520	Anti-Reverse Cam Spring	4307	Anti-Reverse Lock Out	7324	Oscillating Slider Inner
1596	Bushing Washer	4308	Anti-Reverse Pawl	7325	Oscillating Slider
2016	Drag Washer "H" (cloth)	4362	Side Cover Screw	7326	Oscillating Gear
2257	Drag Washer "H" (blue)	4367	Line Roller Screw	7327	Drag Knob
2346	Drag Washer "C" (cloth)	4572	Bail Arm	7328	Handle Assembly
2419	Handle Screw Cap	5625	Line Roller Spacer	7337	Ball Bearing
2433	Pressure Screw	5628	Line Roller Collar	7341	Rotor
2541	Anti-Reverse Pawl Screw	5629	Line Roller Bushing	7342	Pinion Gear
2852	Handle Screw Lock	5630	Line Roller	7343	Drive Gear
3359	Line Roller Washer	5690	Anti-Reverse Lever Screw	7344	Body Set