



| BNT No. | PARTS NAMES | BNT No. | PARTS NAMES | BNT No. | PARTS NAMES |
|---------|---------------------------|---------|------------------------|---------|--------------------------|
| 0042 | Line Guide Pawl | 1853 | Key Washer (A) | 2087 | Quick-Fire II Clutch Bar |
| 0133 | "E" Lock | 1854 | Eared Washer (B-1) | 2092 | Click Plate |
| 0191 | Clutch Bar Support Screw | 1921 | Cast Control Cap | 2093 | Click Switch Spring |
| 0194 | Ball Bearing | 1922 | Cast Control Spacer | 2094 | Click Switch |
| 0425 | "E" Lock | 1927 | Anti-Reverse Ratchet | 2095 | Click Pawl |
| 0609 | Multi-Purpose Screw | 1930 | Clutch Cam Screw | 2097 | Worm Bushing (A) |
| 0664 | Spacer B | 1937 | Line Guide Assembly | 2238 | Bush Plate Screw |
| 0686 | "E" Lock | 1940 | Frame Nut | 2242 | Roller Clutch Inner Tube |
| 0770 | Handle Nut Plate Screw | 1941 | Stand Screw | 2291 | Handle Assembly |
| 0799 | Friction Washer | 1948 | Brake Collar | 2293 | Left Side Plate Nut |
| 0816 | Shaft Washer | 1949 | Right Side Plate Screw | 2298 | Drive Shaft Washer (B) |
| 0819 | Drive Shaft Bushing | 1957 | Worm Bushing (B) | 2305 | Stand Bolt |
| 0830 | Spacer (optional) | 1962 | Thumb Rest | 2312 | Right Side I.D. Plate |
| 1133 | Yoke Spring | 1963 | Level Wind Guard | 2314 | Frame Bar |
| 1201 | Retractor Spring Collar | 1965 | Idle Gear (A) | 2315 | Spool Assembly |
| 1227 | Push Nut (SPN-2) | 1966 | Stand | 2316 | Clutch Bar Support |
| 1239 | Pawl Cap | 1968 | Idle Gear (B) Shaft | 2324 | Star Drag |
| 1245 | Clutch Bar Support Spacer | 1969 | Idle Gear (B) | 2326 | Roller Clutch Assembly |
| 1354 | Click Switch Screw | 1971A | Worm Shaft | 2327 | Return Pin Guide |
| 1455 | Drag Spring Washer (H) | 1972 | Click Spring | 2328 | Drive Gear |
| 1472 | Anti-Reverse Pawl | 1974 | Click Switch Washer | 2329 | Drive Shaft |
| 1613 | Drag Spring Washer (L) | 1976 | Click Shaft | 2330 | Clutch Cam |
| 1616 | Left Side Plate Screw | 2050 | Clutch Cam Retainer | 2331 | Clutch Pawl |
| 1618 | Key Washer (C) | 2076 | Pinion Gear | 2332 | A-Side Seal |
| 1620 | Eared Washer | 2077 | Yoke | 2333 | Set Plate |
| 1692 | Handle Nut Plate | 2078 | Retractor Spring | 2334 | Left Side Frame |
| 1697 | Spool Tension Spring | 2081 | Clutch Pawl Spring | 2337 | Left Side Plate |
| 1788 | Handle Nut | 2083 | Clutch Plate | 2338 | Right Side Frame |
| 1851 | Drag Washer (C) | 2085 | Brake Case | 2339 | B-Side Seal |
| 1852 | Drag Washer (B-2) | 2086 | Clutch Bar Guide | 2340 | Right Side Plate |