


# CU-201 <sup>94</sup>



# CURADO

BNT No.	PARTS NAMES	BNT No.	PARTS NAMES	BNT No.	PARTS NAMES
0015	Drag Spring Washer	1317	Brake Collars (red-6 pieces)	1507	Spool Assembly
0031	Ball Bearing	1344	"C"Lock	1510	Turnkey Dial
0032	Bearing Retainer	1356	Brake Case Retainer Screw	1511	Handle Assembly
0042	Line Guide Pawl	1357	Brake Case	1512	Star Drag Nut
0194	Ball Bearing	1362	Turnkey Pawl	1513	Left Side Plate
0425	"E"Lock	1467	Level Wind Guard	1514	Drive Gear
0664	Spacer (B)	1469	Line Guide	1515	Drive Shaft
0817	Clutch Bar Screw	1486	Star Drag	1516	Drive Shaft Cover
0830	Spacer (optional)	1487	Cast Control Cap Assembly	1517	Clutch Plate
0987	Multi Purpose Screw	1489	Side Plate Screws	1518	Pinion Gear
1092	Pawl Cap	1490	Anti-Reverse Ratchet	1519	Yoke
1106	Star Drag Spring	1492	Idle Gear	1520	Clutch Cam Retainer
1133	Yoke / Turnkey Pawl Spring	1493	Drive Gear Washer	1521	Clutch Cam
1206	Roller Clutch Inner Tube	1494	Drive Shaft Washer (B)	1522	Clutch Pawl
1207	Roller Clutch Bearing	1495	Drive Shaft Washer (A)	1523	Clutch Pawl Spring
1211	Key Washer	1497	Drive Shaft Cover Screw	1524	Thumb Rest
1212	Drag Washer (C)	1498	Worm Shaft Assembly	1525	One-Piece Frame
1214	Drag Washer (A)	1499	Clutch Plate Screw	1526	Quick-Fire II Clutch Bar
1289	Star Drag Spacer	1506	Line Guard	1527	Right Side Plate