



# HYPERLOOP

## 1000RK 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	3744	Drag Click	6790	Counterbalance Cover
0071	Rotor Nut	3747	Slider Retainer Screw	7289	Push Button Collar
0452	Drag Spring Washer	3848	Bail Spring Guide (A)	7290	Push Button
0540	Multi-Purpose Screw	3849	Bail Spring Guide (B)	7291	Spool Assembly
0574	Drag Washer "C" (cloth)	3851	Bail Trip Lever	7292	Main Shaft
0579	Eared Washer "B"	3853	Anti-Reverse Lock Out	7293	Bail Assembly
0584	Hold Click Spring	3854	Anti-Reverse Lock Out Spring	7294	Rotor
0642	Side Cover Screw	3855	Lock Out Spring Holder	7295	Ball Bearing
0779	Multi-Purpose Screw	3856	Anti-Reverse Pawl	7296	Pinion Gear
0787	Nut Lock Screw	3857	Anti-Reverse Pawl Spring	7297	Anti-Reverse Cam
0792	Bearing Retainer Screw	4049	Large Hole Washer	7298	Anti-Reverse Lever
0848	Small Hole Washer	4096	Drag Shaft	7299	Drive Gear
1008	Handle Lock Washer	4097	Pressure Screw	7300	Oscillating Slider Retainer
1891	Bail Spring Cover Screw	4099	Drag Knob Screw	7301	Oscillating Slider Inner
2257	Drag Washer "H" (blue)	4367	Line Roller Screw	7302	Oscillating Slider
2283	Anti-Reverse Pawl Screw	4568	Bail Arm	7303	Oscillating Gear
2293	Drive Gear Bushing	5625	Line Roller Spacer	7304	Oscillating Gear Bushing
2419	Handle Screw Cap	5628	Line Roller Collar	7305	Drag Spring
2852	Handle Screw Lock	5629	Line Roller Bushing	7306	Drag Knob
3359	Line Roller Washer	5630	Line Roller	7307	Handle Assembly
3397	Bail Spring	5690	Anti-Reverse Lever Screw	7371	Side Cover
3402	Cover Screw	5996	Locking Spring	7372	Body
3471	Anti-Reverse Cam Spring	6787	Bail Spring Cover		