



HYPERLOOP

4000RK 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	3402	Cover Screw	6797	Bail Spring Cover
0071	Rotor Nut	3681	Bail Spring Guide (A)	6800	Counterbalance Cover
0452	Drag Spring Washer	3682	Bail Spring	7290	Push Button
0540	Multi-Purpose Screw	3683	Bail Spring Guide (B)	7295	Ball Bearing
0579	Eared Washer "B"	3747	Slider Retainer Screw	7298	Anti-Reverse Lever
0584	Hold Click Spring	3765	Drag Click	7305	Drag Spring
0779	Multi-Purpose Screw	3794	Drag Knob Screw	7314	Push Button Collar
0787	Nut Lock Screw	3869	Anti-Reverse Lock Out Spring	7320	Pinion Gear
0792	Bearing Retainer Screw	3873	Anti-Reverse Pawl Spring	7321	Anti-Reverse Cam
0826	Key Washer "A"	3886	Bail Trip Lever	7322	Drive Gear
0848	Small Hole Washer	4049	Large Hole Washer	7323	Oscillating Slider Retainer
1008	Handle Lock Washer	4274	Drag Shaft	7324	Oscillating Slider Inner
1511	Lever Spring	4306	Lock Out Spring Holder	7325	Oscillating Slider
1520	Anti-Reverse Cam Spring	4307	Anti-Reverse Lock Out	7326	Oscillating Gear
1596	Bushing Washer	4308	Anti-Reverse Pawl	7327	Drag Knob
2016	Drag Washer "H" (cloth)	4362	Side Cover Screw	7330	Spool Assembly
2257	Drag Washer "H" (blue)	4367	Line Roller Screw	7331	Main Shaft
2293	Drive Gear Bushing	4572	Bail Arm	7332	Bail Assembly
2346	Drag Washer "C" (cloth)	5625	Line Roller Spacer	7333	Rotor
2419	Handle Screw Cap	5628	Line Roller Collar	7334	Handle Assembly
2433	Pressure Screw	5629	Line Roller Bushing	7375	Body
2541	Anti-Reverse Pawl Screw	5642	Line Roller	7376	Side Cover
2852	Handle Screw Lock	5690	Anti-Reverse Lever Screw		
3359	Line Roller Washer	5996	Locking Spring		