


SEDONA



RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	4421	Handle Screw Cap	5206	Pinion Gear
0041	Drive Gear Washer	4649	Spacer	5207	Anti-Reverse Cam
0050	Anti-Reverse Lever Screw	4650	Bail Hold Support Shaft	5208	Anti-Reverse Lever
0071	Rotor Nut	4652	Lever Spring Guide (B)	5209	Drive Gear
0787	Nut Lock Screw	4654	Lever Spring Guide (A)	5212	Oscillating Slider
0930	Ball Bearing	4656	Trip Lever Spacer	5213	Oscillating Gear
1008	Handle Lock Washer	4661	Anti-Reverse Cam Ring	5548	Handle Assembly
1506	Clutch Cover Screw	4698	Bail Spring Guide (A)	5625	Line Roller Spacer
1520	Anti-Reverse Cam Spring	4699	Bail Spring	5628	Line Roller Collar
1891	Bail Hold Support Guard Screw	4700	Bail Spring Guide (B)	5629	Line Roller Bushing
2293	Drive Gear Bushing	4701	Bail Arm Screw	5630	Line Roller
2404	"E" Lock	4702	Bail Arm Bushing	5661	Bail Assembly
2516	Spool Support	4710	Lever Spring	5670	Body Assembly
2852	Handle Screw Lock	4711	Bail Trip Lever	6606	Side Cover Screw (short)
3309	Line Roller Screw	4714	Roller Clutch Assembly	6825	Spool Assembly (graphite)
3359	Line Roller Washer	4823	Bail Arm	6993	Spool Assembly (aluminum)
3402	Bail Spring Cover Screw (small)	4826	Bail Hold Support Spacer	6999	Rotor Assembly
3503	Spool Washer	4829	Roller Clutch Screw	7665	Bail Spring Cover Screw (large)
3665	Slider Retainer Screw	5199	Drag Knob		
4362	Side Cover Screw (long)	5201	Main Shaft		