


SIDESTAB 4000RD 01



RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	2433	Pressure Screw	4282	Drive Gear
0041	Drive Gear Washer	2541	Anti-Reverse Pawl Screw	4290	Main Shaft Assembly
0050	Anti-Reverse Lever Screw	2852	Handle Screw Lock	4310	Drag Click
0071	Rotor Nut	3359	Line Roller Washer	4362	Side Cover Screw
0111	Drag Coil Spring	3402	Cover Screw	4367	Line Roller Screw
0452	Drag Spring Washer	3681	Bail Spring Guide (A)	4373	Quick-Fire II Trigger
0540	Multi-Purpose Screw	3682	Bail Spring	4375	Bail Arm
0579	Eared Washer "B"	3683	Bail Spring Guide (B)	4421	Handle Screw Cap
0584	Hold Click Spring	3685	Bail Trip Lever	4906	Anti-Reverse Lever
0779	Bail Hold Support Screw	3688	Anti-Reverse Lock Out	4926	Drag Knob Assembly
0786	Trigger Screw	3692	Anti-Reverse Pawl Spring	5548	Handle Assembly
0787	Nut Lock Screw	3695	Oscillating Gear	5625	Line Roller Spacer
0792	Bearing Retainer Screw	3747	Slider Retainer Screw	5628	Line Roller Collar
0826	Key Washer "A"	3766	Oscillating Slider	5629	Line Roller Bushing
0930	Ball Bearing	3767	Oscillating Slider Retainer	5630	Line Roller
1008	Handle Lock Washer	3794	Drag Knob Screw	6735	Bail Assembly
1511	Lever Spring	3869	Anti-Reverse Lock Out Spring	7053	Anti-Reverse Ratchet
1520	Anti-Reverse Cam Spring	4161	Trigger Cam	7096	Spool Assembly
1596	Bushing Washer	4270	Anti-Reverse Pawl	7097	Body Set
2016	Drag Washer "H" (cloth)	4271	Anti-Reverse Cam	7098	Rotor Assembly
2257	Drag Washer "H" (blue)	4274	Drag Shaft		
2346	Drag Washer "C" (cloth)	4281	Pinion Gear		