



TGT No.	PARTS NAMES	TGT No.	PARTS NAMES	TGT No.	PARTS NAMES
0002	Handle Nut Plate	0083	Right Side Plate	0105	Yoke
0014	Lock Washer	0084	Cast Control Cap	0108	Line Guard Screw
0016	Clutch Spring	0085	Spacer	0109	Right Side Plate Screw (B)
0031	Drive Shaft Bushing	0086	Spool Tension Spring	0111	Click Gear Retainer
0032	Spacer	0087	Clutch Lever Screw	0112	Ball Bearing
0033	Drive Shaft Retainer	0088	Clutch Lever	0113	Left Side Plate
0037	Anti-Reverse Pawl	0090	Ball Bearing	0114	Left Side Plate Screw
0039	Anti-Reverse Pawl Spring	0091	Bearing Thrust Washer	0117	Line Guard
0052	Ball Bearing	0092	Drag Spring Washer	0118	Spool
0054	Click Gear	0093	Key Washer "F"	0128	Handle Nut Plate Screw
0058	Spacer "B"	0094	Drag Washer "D"	0129	Handle Nut
0062	Click Pawl Retainer	0095	Eared Washer "E"	0138	"O" Ring
0065	Spacer A	0096	Drag Washer "I"	0208	Yoke Spring
0067	Click Spring	0097	Key Washer "C"	0243	Frame
0068	Click Spring Screw	0098	Eared Washer "B"	0259	Yoke Plate
0078	Handle Washer	0099	Drive Gear	0414	Handle Assembly
0079	Star Drag	0100	Drive Shaft Washer	0417	Clutch Cam
0080	Star Drag Washer	0101	Anti-Reverse Ratchet	0420	Spacer B
0081	Right Side Plate Screw (A)	0102	Drive Shaft	0421	Click Pawl
0082	Spool Shaft Bushing	0103	Pinion Gear	0423	Click Button