


SPHEROS 12000FA 02



RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0088	Line Roller Screw	5811	Bail Arm Screw	7586	Drag Knob
0244	Ball Bearing	5812	Bail Arm Screw Collar	7587	Spool Assembly
0540	Worm Shaft Retainer Screw	5813	Guard Screw (A)	7588	Spool Support
0757	Drive Gear Washer	5814	Bail Trip Lever Screw	7589	Main Shaft
1506	Roller Clutch Cover Screw	5816	Bail Trip Lever	7590	Line Roller Screw Cap
1676	Side Cover Screw (long)	5820	Spacer	7591	Bail Arm
2298	Spacer	5823	Lever Spring Guide (A)	7592	Bail Spring Cover
2409	Worm Shaft Spacer	5825	Lever Spring Guide (B)	7593	Bail Assembly
3204	Ball Bearing	5828	Worm Bushing (front)	7594	Bail Hold Support Spacer
3306	Line Roller Bearing	5832	Worm Bushing (rear)	7595	Rotor
3600	Nut Lock Screw	5834	Anti-Reverse Cam Spring	7596	Worm Shaft
4004	Drive Gear Bushing	5838	Oscillating Pawl	7597	Anti-Reverse Lever Screw
4743	Line Roller Bushing	5839	Oscillating Slider Bushing	7598	Anti-Reverse Lever
4744	Roller Bearing Seal	5855	Oscillating Guide Holder	7599	Friction Ring
5040	Roller Clutch Screw	5884	Rotor Nut	7600	Drive Gear
5042	Anti-Reverse Cam Ring	5922	Oscillating Pawl Retainer Screw	7601	Oscillating Slider
5447	Roller Clutch Assembly	5941	Side Cover Screw (short)	7602	Oscillating Slider Retainer
5705	Roller Clutch Ring	5997	Line Roller	7603	Side Cover
5717	Ball Bearing	6127	Bail Hold Support Screw	7604	Worm Shaft Retainer
5799	Rotor Nut Retainer	6172	Bail Hold Support Shaft	7605	Oscillating Guide
5801	Line Roller Washer	6286	Bail Trip Lever Spring	7606	Body I.D.Plate (B)
5803	Bail Spring Guide (A)	6724	Idle Gear (B)	7607	Body
5804	Spring Guide (A) Support	7428	Bail Trip Lever Washer	7608	Handle Assembly
5805	Bail Spring	7432	Anti-Reverse Cam	7616	Spool Washer
5806	Bail Spring Guide (B)	7458	Line Roller Support Collar	7617	Slider Retainer Screw
5808	Bail Arm Washer	7568	Handle Screw Cap	7713	Pinion Gear