



SPIREX 1000 RB 00

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	3471	Anti-Reverse Cam Spring	4421	Handle Screw Cap
0041	Drive Gear Washer	3656	Anti-Reverse Ratchet	4535	Double Paddle Handle Assembly
0050	Anti-Reverse Lever Screw	3658	Anti-Reverse Pawl	4546	Pressure Screw
0071	Rotor Nut	3659	Anti-Reverse Pawl Spring	5190	Anti-Reverse Lever
0540	Multi-Purpose Screw	3663	Oscillating Gear	5458	Rotor
0582	"O" Ring	3742	Drive Gear	5461	Bail Spring Cover
0642	Side Cover Screw	3743	Hold Click Spring	5462	Bail Trip Lever
0779	Bail Hold Support Screw	3745	Oscillating Slider	5463	Counterbalance Cover
0786	Trigger Screw	3746	Oscillating Slider Retainer	5464	Pinion Gear
0787	Nut Lock Screw	3747	Slider Retainer Screw	5465	Anti-Reverse Cam
0792	Bearing Retainer Screw	3749	Drag Washer "C" (white)	5501	Spool Assembly (aluminum)
0930	Ball Bearing	3750	Eared Washer "B"	5502	Spool Assembly (graphite)
1008	Handle Lock Washer	3754	Drag Spring Washer	5503	Main Shaft
1890	Bushing Washer	3775	Drag Click	5504	Side Cover
1891	Bail Spring Cover Screw	3776	Drag Washer "C" (cloth)	5505	Drag Shaft (A)
1974	Drag Coil Spring	3777	Click Gear	5506	Drag Shaft (B)
2280	Anti-Reverse Lock Out	3778	Eared Washer "Br"	5507	Fightin' Drag Lever
2283	Anti-Reverse Pawl Screw	3781	Lever Click Gear	5508	Drag Programmer
2852	Handle Screw Lock	3782	Fightin' Pressure Screw Washer	5509	Body
3125	Drag Click Screw	3783	Fightin' Pressure Screw	5625	Line Roller Spacer
3306	Line Roller Bearing	3785	Lever Hold Spring	5630	Line Roller
3309	Line Roller Screw	3787	Drag Programmer Screw	5909	Line Roller Bushing
3396	Bail Spring Guide (A)	3869	Anti-Reverse Lock Out Spring	6622	Line Roller Washer
3397	Bail Spring	4160	Trigger Cam	6623	Bearing Spacer
3398	Bail Spring Guide (B)	4364	Quick-Fire II Trigger	6624	Bail Assembly
3402	Cover Screw	4366	Bail Arm		