



SUPER X

4000GT 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	5253	Oscillating Guide	6354	Bail Spring
0041	Drive Gear Washer	5257	Oscillating Guide Retainer	6355	Bail Spring Guide (B)
0071	Rotor Nut	5261	Slider Retainer Screw	6359	Bail Trip Lever
0345	Anti-Reverse Lever Screw	5262	Oscillating Slider Retainer	6442	Rotor Protector
0589	Lever Hold Spring	5263	Oscillating Slider	6603	Drive Gear
0959	Bail Hold Support Screw	5264	Eared Washer "Br"	6739	Protector Screw (large)
1008	Handle Lock Washer	5266	Drag Washer "H" (cloth)	6747	Bail Arm Screw
1442	Handle Screw Cap	5269	Drag Washer "H" (blue)	6894	Oscillating Slider Bushing
1506	Clutch Cover Screw	5270	Eared Washer "B"	6919	Roller Clutch Assembly
1520	Anti-Reverse Cam Spring	5275	Hold Click Spring	6920	Spacer
1676	Side Cover Screw (long)	5276	Lever Click Gear	6922	Worm Bushing
2094	Spacer	5277	Fightin' Pressure Screw Washer	6923	Worm Shaft
2293	Drive Gear Bushing	5278	Fightin' Pressure Screw	6924	Anti-Reverse Cam
2298	Spacer	5310	Bushing	6925	Idle Gear
2346	Drag Washer "C" (cloth)	5311	Anti-Reverse Lever	6932	Drag Shaft (A)
2347	Click Gear	5338	Drag Washer "C" (cloth)	6937	Main Shaft
2348	Drag Washer "C" (blue)	5339	Drag Shaft (B)	7003	Bail Hold Support Shaft
2353	Drag Programmer Screw	5340	Key Washer "A"	7004	Bail Hold Support Spacer
2409	Worm Shaft Spacer	5341	Drag Coil Spring	7019	Bail Spring Cover
2852	Handle Screw Lock	5342	Drag Spring Washer	7020	Bail Arm
3282	Roller Clutch Screw	5343	Pressure Screw	7021	Bail Assembly
3306	Ball Bearing	5344	Hold Click Spring Washer	7022	Rotor
3655	Protector Screw (small)	5880	Nut Lock Screw	7024	Rear Cover Screw (long)
4254	Rear Cover Screw (short)	6077	Click Pin	7026	Side Cover Screw (medium)
4403	Line Roller Screw	6085	Line Roller	7027	Side Cover Screw (small)
4490	Double Paddle Handle Assembly	6132	Friction Ring	7028	Body
4652	Lever Spring Guide (B)	6290	Rotor Nut Lock Plate	7035	Fightin' Drag II Lever
4653	Lever Spring	6296	Click Spring	7036	Drag Programmer
4654	Lever Spring Guide (A)	6329	Bearing Spacer	7042	Side Cover Assembly
4656	Trip Lever Spacer	6330	Line Roller Bushing	7044	Spool Assembly
4678	Oscillating Pawl	6331	Line Roller Spacer	7045	Rear Cover
4838	Drive Gear Bushing	6332	Line Roller Washer	7288	Pinion Gear
5222	Idle Gear Lock	6353	Bail Spring Guide (A)		