



# SUPER X 4000GTM 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	5253	Oscillating Guide	6332	Line Roller Washer
0041	Drive Gear Washer	5255	Worm Shaft	6353	Bail Spring Guide (A)
0071	Rotor Nut	5256	Idle Gear	6354	Bail Spring
0345	Anti-Reverse Lever Screw	5257	Oscillating Guide Retainer	6355	Bail Spring Guide (B)
0589	Lever Hold Spring	5261	Slider Retainer Screw	6359	Bail Trip Lever
0959	Bail Hold Support Screw	5262	Oscillating Slider Retainer	6442	Rotor Protector
1008	Handle Lock Washer	5263	Oscillating Slider	6525	Drive Gear
1442	Handle Screw Cap	5264	Eared Washer "Br"	6739	Protector Screw (large)
1506	Clutch Cover Screw	5266	Drag Washer "H" (cloth)	6747	Bail Arm Screw
1520	Anti-Reverse Cam Spring	5269	Drag Washer "H" (blue)	6894	Oscillating Slider Bushing
1676	Side Cover Screw (long)	5270	Eared Washer "B"	6919	Roller Clutch Assembly
2094	Spacer	5275	Hold Click Spring	6920	Spacer
2293	Drive Gear Bushing	5276	Lever Click Gear	6922	Worm Bushing
2298	Spacer	5277	Fightin' Pressure Screw Washer	6924	Anti-Reverse Cam
2346	Drag Washer "C" (cloth)	5278	Fightin' Pressure Screw	6932	Drag Shaft (A)
2347	Click Gear	5310	Bushing	6935	Spool Assembly
2348	Drag Washer "C" (blue)	5311	Anti-Reverse Lever	6937	Main Shaft
2353	Drag Programmer Screw	5338	Drag Washer "C" (cloth)	7003	Bail Hold Support Shaft
2409	Worm Shaft Spacer	5339	Drag Shaft (B)	7004	Bail Hold Support Spacer
2852	Handle Screw Lock	5340	Key Washer "A"	7019	Bail Spring Cover
3282	Roller Clutch Screw	5341	Drag Coil Spring	7020	Bail Arm
3306	Ball Bearing	5342	Drag Spring Washer	7021	Bail Assembly
3655	Protector Screw (small)	5343	Pressure Screw	7022	Rotor
4254	Rear Cover Screw (short)	5344	Hold Click Spring Washer	7024	Rear Cover Screw (long)
4403	Line Roller Screw	5880	Nut Lock Screw	7026	Side Cover Screw (medium)
4490	Double Paddle Handle Assembly	6077	Click Pin	7027	Side Cover Screw (small)
4652	Lever Spring Guide (B)	6085	Line Roller	7028	Body
4653	Lever Spring	6132	Friction Ring	7032	Match Spool Assembly
4654	Lever Spring Guide (A)	6290	Rotor Nut Lock Plate	7033	Side Cover Assembly
4656	Trip Lever Spacer	6296	Click Spring	7034	Rear Cover
4678	Oscillating Pawl	6329	Bearing Spacer	7035	Fightin' Drag II Lever
4838	Drive Gear Bushing	6330	Line Roller Bushing	7036	Drag Programmer
5222	Idle Gear Lock	6331	Line Roller Spacer	7287	Pinion Gear