


SX



6000

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0050	Anti-Reverse Lever Screw	4008	Oscillating Slider	5208	Anti-Reverse Lever
0521	Rotor Nut	4362	Side Cover Screw	5440	Drag Knob
0540	Bail Spring Cover Screw (large)	4441	Handle Screw Cap	5442	Main Shaft
0690	Drive Gear Washer	4649	Spacer	5447	Roller Clutch Assembly
0787	Nut Lock Screw	4656	Trip Lever Spacer	5448	Pinion Gear
0998	Multi-Purpose Screw	4745	Bail Spring Guide (A)	5449	Anti-Reverse Cam
1008	Handle Lock Washer	4746	Bail Spring Guide (A) Support	5450	Drive Gear
1109	Slider Retainer Screw	4747	Bail Spring	5454	Handle Assembly
1506	Clutch Cover Screw	4748	Bail Spring Guide (B)	5455	Anti-Reverse Cam Spring
2404	"E" Lock	4749	Bail Arm Screw	5456	Lever Spring
3182	Spool Support	4750	Bail Arm Bushing	5625	Line Roller Spacer
3204	Ball Bearing	4756	Bail Hold Support Shaft	5628	Line Roller Collar
3309	Line Roller Screw	4758	Lever Spring Guide (B)	5629	Line Roller Bushing
3359	Line Roller Washer	4760	Lever Spring Guide (A)	5642	Line Roller
3387	Handle Screw Lock	4761	Bail Trip Lever	5999	Spool Assembly
3402	Bail Spring Cover Screw (small)	5034	Bail Arm	6000	Bail Assembly
3503	Spool Washer	5037	Bail Hold Support Spacer	6001	Body Assembly
4004	Drive Gear Bushing	5040	Roller Clutch Screw	6002	Rotor Assembly
4006	Oscillating Gear Bushing	5041	Bushing		
4007	Oscillating Gear	5042	Anti-Reverse Cam Ring		