



1000FA 00

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	3400	Bail Trip Lever	3869	Anti-Reverse Lock Out Spring
0041	Drive Gear Washer	3402	Cover Screw	4051	Bail Spring
0050	Anti-Reverse Lever Screw	3450	Spool Assembly (graphite)	4160	Trigger Cam
0071	Rotor Nut	3455	Spool Washer	4364	Quick-Fire II Trigger
0540	Multi-Purpose Screw	3471	Anti-Reverse Cam Spring	4366	Bail Arm
0642	Side Cover Screw	3646	Main Shaft	4367	Line Roller Screw
0779	Bail Hold Support Screw	3651	Bail Spring Guide (A)	4421	Handle Screw Cap
0786	Trigger Screw	3652	Bail Spring Guide (B)	4885	Drag Knob
0787	Nut Lock Screw	3656	Anti-Reverse Ratchet	4886	Spool Assembly (aluminum)
0792	Bearing Retainer Screw	3657	Pinion Gear	4890	Anti-Reverse Lever
0930	Ball Bearing	3658	Anti-Reverse Pawl	4927	Side Cover
1008	Handle Lock Washer	3659	Anti-Reverse Pawl Spring	4928	Body
1427	Spool Support	3660	Anti-Reverse Cam	5546	Handle Assembly
1890	Bushing Washer	3662	Drive Gear	5625	Line Roller Spacer
1891	Bail Spring Cover Screw	3663	Oscillating Gear	5628	Line Roller Collar
2280	Anti-Reverse Lock Out	3664	Oscillating Slider	5629	Line Roller Bushing
2283	Anti-Reverse Pawl Screw	3665	Slider Retainer Screw	5630	Line Roller
2293	Drive Gear Bushing	3700	Rotor	6733	Bail Assembly
2852	Handle Screw Lock	3702	Bail Spring Cover		
3359	Line Roller Washer	3703	Counterbalance Cover		