


TRINIDAD

TN 30 ⁰⁰



TGT No.	PARTS NAMES	TGT No.	PARTS NAMES	TGT No.	PARTS NAMES
0033	Drive Shaft Retainer	0285	Clutch Lever Screw	0321	"BR" Friction Washer
0058	Spacer "B"	0286	Roller Clutch Inner Tube	0322	"BR" Washer (C)
0062	Click Pawl Retainer	0287	Key Washer	0323	"BR" Washer (A)
0065	Spacer (A)	0288	Drag Washer (D)	0324	"BR" Gear (C)
0111	Click Gear Retainer	0289	Eared Washer (E)	0325	"BR" Washer (B)
0112	Ball Bearing	0290	Key Washer (C)	0326	Click Pawl Spring
0128	Handle Nut Plate Screw	0291	Drag Washer (B)	0327	"BR" Set Plate
0182	Cast Control Spacer (A)	0292	Drive Gear	0328	"BR" Set Plate Screw
0185	"O" Ring	0294	Anti-Reverse Ratchet	0329	Spacer (B)
0257	Brake Collar	0295	Click Pin	0330	Click Pawl
0261	Handle Nut Plate	0296	Click Spring	0331	Click Pawl Spacer
0262	Handle Nut	0297	Drive Shaft	0332	Click Spring Retainer
0263	Handle Assembly	0298	Drive Shaft Washer (B)	0333	Click Spring
0264	Drive Shaft Shield	0299	Yoke Spring	0334	Click Spring Holder
0265	Star Drag	0300	Yoke	0335	"BR" Click Spring
0266	Star Drag Washer	0301	Pinion Gear	0336	"BR" Click Pin
0267	Drag Spring Washer (9L)	0302	Yoke Plate	0337	Left Side Plate Screw
0268	Drag Spring Washer (9H)	0303	Anti-Reverse Pawl	0338	"BR" Washer (D)
0269	Bearing Thrust Washer	0304	Set Plate Screw (B)	0339	"BR" Dial
0270	Bearing Seal	0305	Multi-Purpose Screw	0340	Left Side Plate
0271	Ball Bearing	0306	Anti-Reverse Pawl Keeper	0341	Click Button
0272	Right Side Plate Screw (D)	0307	Set Plate	0342	Right Side Plate
0273	Right Side Plate Screw (C)	0308	Set Plate Screw (A)	0343	One-Piece Frame
0274	Right Side Plate Screw (A)	0309	Ball Bearing	0344	Spool Assembly
0276	Cast Control Cap	0310	Drive Shaft Washer (A)	0348	Spacer (C)
0277	Cast Control Spacer (B)	0312	Brake Shaft Holder Screw	0418	Drag Washer (A)
0278	Clutch Lever	0313	Brake Shaft Holder		
0279	Smoother	0315	Click Gear	0351	Rod Clamp Bolt (accessory)
0280	Line Clip	0316	Spool Shaft Spacer	0352	Rod Clamp Nut (B) (accessory)
0281	Roller Clutch Bearing	0317	"BR" Gear (A)	0353	Rod Clamp (accessory)
0282	Eccentric Cam Bushing	0318	Bearing Retainer	0354	Rod Clamp Nut (A) (accessory)
0283	Clutch Spring	0319	"BR" Cam Pin		
0284	Clutch Cam	0320	"BR" Cam	0355	Wrench (accessory)